




# HP Envy 17-3070NR Back Cover Replacement

Follow this guide if you want to replace the back cover of your HP Envy 17-3070NR.



Written By: Abby Lentz




 **TOOLS:**

- [Phillips #2 Screwdriver](#) (1)
-




## Step 1 — Back Cover



 Before you begin taking apart the computer, make sure that it is completely powered off.

- Slide the release latch away from the nearest edge.
- Slide the back cover off of the computer.

## Step 2



- Remove the six 3.7mm Phillips screws.
- Slide the back cover until it clicks, then lift it straight off.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-08-24 07:38:00 PM.