



iPod Nano 2nd Generation Bottom Bezel Replacement

Written By: iRobot



INTRODUCTION

The plastic part on the bottom of the iPod.



TOOLS:

- [iFixit Opening Tools](#) (1)



PARTS:

- [iPod Nano Gen 2 Bottom Bezel](#) (1)
-

Step 1 — Bottom Bezel



- ⓘ Before opening your iPod, ensure that the hold switch is in the locked position.

Step 2



- ⚠ When removing the the bottom bezel, be sure not to bend the plastic surrounding the dock connector.
- Carefully insert an iPod opening tool in the seam between the metal casing and white plastic bezel
- Lift the bottom bezel off the iPod. It's glued on using a mild adhesive, so some force may be required.

To reassemble your device, follow these instructions in reverse order.