



HTC One M9 MicroSD Card Replacement

Replace the microSD card.

Written By: Geoff Wacker



INTRODUCTION

Use this guide to replace the microSD card on your HTC One M9.

TOOLS:

- [SIM Card Eject Tool](#) (1)
-

Step 1 — MicroSD Card



- Insert a microSD card eject tool or a paperclip into the small hole in the microSD card tray, located on the upper right hand side of the phone above the volume buttons.
- Press to eject the tray.
 - ⓘ This may require a significant amount of force.
- ☑ When reinserting the microSD card, ensure that it is in the proper orientation relative to the tray. The connectors should be inserted first and away from you (if the display was face up).
- ⓘ It is normal, that the microSD card doesn't sit perfectly within the tray. It is also very simple to place it correctly flat inside the tray.

To reassemble your device, follow these instructions in reverse order.