



Sharp Aquos LC13B2UA Stand Replacement

How to replace a Sharp Aquos LC13B2UA stand.

Written By: Robert Hobson



TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-

Step 1 — Stand



- Place the TV face down on a flat smooth surface as to not scratch the screen.
- Using a Phillips #2 screwdriver remove the four 8mm screws attaching the stand to the TV.

Step 2



- Lift the stand off the television.

To reassemble your device, follow these instructions in reverse order.