



Sharp Aquos LC13B2UA Stand Replacement

For the replacement of a television stand.

Written By: Robert Hobson



 **TOOLS:**

- Phillips #2 Screwdriver (1)
-

Step 1 — Stand



- Place the TV face down on a flat smooth surface as to not scratch the screen.
- Remove the four 8mm screws attaching the stand to the TV.

Step 2



- Lift the stand off the television.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-16 01:50:23 PM.