




# Fixing an iPhone 5 with disabled wireless switch

This technique shows how to fix an issue where the Wi-Fi setting is greyed out, and cannot be enabled.

Written By: Mario



## Step 1 — Fixing an iPhone 5 with disabled wireless switch



- Make sure to try these methods before using this guide: 1. Reset Network settings 2. Restart iPhone 3. Restore iPhone to factory settings 4. Go to Settings, Date and Time, change date and time to manual, and restart iPhone 5. Disconnect and reconnect the battery If these procedures fail, proceed to the next section.
- ⓘ If these procedures fail, proceed to the next step.

To reassemble your device, follow these instructions in reverse order.