



Canon EOS Rebel XS Eyepiece Replacement

Written By: Daniel Bussone



INTRODUCTION

Use this guide in order to replace the exterior eyepiece or to access the top cover screws.

Step 1 — Eyepiece



- Grasp the eyepiece with your fingers and slide upwards to remove it.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-17 03:37:50 PM.