



# Presto PopLite 04820 Baseplate Replacement

Replace the baseplate in your Presto PopLite 04820.

Written By: Emanuele Rocco



---

## INTRODUCTION

Use this guide to replace the baseplate in your Presto PopLite 04820.

---

### TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-


## Step 1 — Baseplate



**⚠** Be sure that the popper is unplugged before disassembly.

- Turn Presto Popper upside down.

## Step 2



- Remove the four 9 mm Phillips #2 screws from the base.
- Once all four screws are removed, take the base off.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-08-21 09:37:02 PM.