



# Bose Soundlink II Cover Removal

Use this guide to remove the cover and access the section underneath it.

Written By: Kevin Bailey



---

## INTRODUCTION

This guide will outline the process of removing the cover.

---

### TOOLS:

- [T10 Torx Screwdriver](#) (1)
-

## Step 1 — Bose Soundlink II Cover Removal



- Using a screwdriver with a T-star torque, remove the two 13 mm screws from the bottom of the speaker.

## Step 2



- Pull on the black tab that says "BOSE" on the front cover.
- The back of the cover is latched on by two 13 mm screws. To remove the cover, you must move the back of the cover upwards to unlatch from the screws.

To reassemble your device, follow these instructions in reverse order.