



HP Photosmart D110a Ink Cartridge Replacement

This guide will explain how to replace the ink cartridge on an HP Photosmart D110a printer.

Written By: Tim Wise



INTRODUCTION

Replacing the ink cartridge is easy and requires no technical skill or tools.

Required Tools

- None

Step 1 — Ink Cartridge



- In order to remove the old cartridge, open the mouth of the printer by pulling down on it.
- There are two pieces to the mouth, make sure to pull down both.

Step 2



- Press down on the head of the ink cartridge that needs replacing. This will release the cartridge and allow you to pull it out.
- ☑ Remember the orientation of the old cartridge. The new cartridge will be placed in the slot with the same orientation.

Step 3



- Place the new cartridge into the slot and press firmly until it pops into place.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 05:37:12 AM.