



BlackBerry Curve 8520 Battery Replacement

Learn how to remove and replace the battery of the BlackBerry 8520.

Written By: Matt



INTRODUCTION

Remove the battery of the BlackBerry Curve 8520.



PARTS:

- [BlackBerry Curve 8520 Battery](#) (1)
-

Step 1 — Back Panel



- Insert a plastic opening tool into the small notch on the rear cover of the phone.
- Pry the rear cover up from the phone.

Step 2 — Battery



- Locate the slit between the top of the battery and the casing.
- Gently apply pressure on the top of the battery to trigger the spring release.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-31 06:07:17 PM.