



Repairing HP Photosmart D110a Paper Jam

How to fix a paper jam in an HP Photosmart D110a printer.

Written By: Tim Wise



INTRODUCTION

This guide will explain how to remove stuck paper from your HP Photosmart D110a printer.

Step 1 — Repairing HP Photosmart D110a Paper Jam



- Identify the location where the piece of paper is jammed.

Step 2



- Use your hand to gently remove the jammed paper.
- Pull the paper until it is completely removed from the printer.

Step 3



- Dispose of paper that caused the jam. Replace the jammed paper with fresh, unwrinkled paper.