



How to Reset / Restore Windows Tablet

How to Reset / Restore Windows Tablet

Written By: ZFix



Windows 8 tablet



how to
reset
refresh


INTRODUCTION

If you have forgotten Password, PIN, if you want to erase or refresh your tablet, you can do reset your tablet from the Troubleshoot menu.

Warning! A reset returns Surface to its factory settings!

[video: <https://www.youtube.com/watch?v=9Z85D2DG9MU>]

Step 1 — How to Reset / Restore Windows Tablet





- Connect the charger.
- Select "Ease of Access".
- Open "On-Screen Keyboard".

Step 2





- Tab the Shift key.
- Reset the tablet.
- After the reset the tablet will start in **Troubleshooting** mode.

Step 3




- Select:
 - Troubleshoot
 - Reset your PC

Step 4



- Follow instructions on the screen to reset your tablet.

Step 5



- This will reset and restore your tablet to its factory settings.
- That's all.
- .
- .
- .
- .
- **Did you do it successfully?**

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-05-24 02:53:15 PM.