



Macintosh PowerBook 1400 Series Battery Replacement

In order to disassemble the the Macintosh PowerBook 1400c to repair any problem, you must first remove the battery.

Written By: Corinne Schnieders



INTRODUCTION

In this guide we will show you how to remove the battery from your Macintosh PowerBook 1400c.

Step 1 — Battery



- Turn the device upside down and then locate the battery latch near the front of the device.

Step 2



- Slide the latch to the left to release the battery.

Step 3



- Continue holding the latch then gently pull the battery out of the device.
- ⓘ Place the battery in a safe location.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-11 09:42:04 AM.