



PowerBook G4 Aluminum 12" 1-1.5 GHz Battery Replacement

Written By: iRobot



INTRODUCTION

Changing the battery is easy -- all you need is a coin.



TOOLS:

- [Coin](#) (1)



PARTS:

- [G4 Aluminum 12" Battery](#) (1)

Step 1 — Battery



- Use a coin to turn the battery locking screw 90 degrees to the right.
- Lift the battery out of the computer.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-11 07:09:50 AM.