



PowerBook 3400 M3553 Battery Replacement

How to remove the PowerBook's battery.

Written By: Michael Mondragon



INTRODUCTION

Before performing any maintenance or repairs ensure that the PowerBook is unplugged and the battery has been removed.

Step 1 — Battery



- Close the screen and turn the PowerBook over. Orient the computer so the text of the label is right side up.

Step 2



- Press and hold the button on the left of the front side, and slide the battery out.

To reassemble your device, simply slide the battery back into the slot until it snaps into place.