



iPhone 6s Pentalobe Screws Replacement

Remove or replace the Pentalobe screws in an iPhone 6s.

Written By: Evan Noronha



INTRODUCTION

Follow this guide to remove or replace the Pentalobe screws in an iPhone 6s.



TOOLS:

- [P2 Pentalobe Screwdriver iPhone](#) (1)



PARTS:

- [iPhone 6s 6s Plus 7 7 Plus Bottom Screws](#) (1)

Step 1 — Pentalobe Screws



⚠ Before disassembling your iPhone, discharge the battery below 25%. A charged lithium-ion battery can catch fire and/or explode if accidentally punctured.

- Power off your iPhone before beginning disassembly.
- Remove the two 3.4 mm P2 Pentalobe screws on the bottom edge of the iPhone, next to the Lightning connector.

To reassemble your device, follow these instructions in reverse order.