



iPhone 6s Pentalobe Screws Replacement

Remove or replace the Pentalobe screws in an iPhone 6s.

Written By: Evan Noronha



INTRODUCTION

Follow this guide to remove or replace the Pentalobe screws in an iPhone 6s.



TOOLS:

- [P2 Pentalobe Screwdriver iPhone](#) (1)



PARTS:

- [iPhone 6s 6s Plus 7 7 Plus Bottom Screws](#) (1)

Step 1 — Pentalobe Screws



⚠ Before disassembling your iPhone, discharge the battery below 25%. A charged lithium-ion battery can catch fire and/or explode if accidentally punctured.

- Power off your iPhone before beginning disassembly.
- Remove the two 3.4 mm P2 Pentalobe screws on the bottom edge of the iPhone, next to the Lightning connector.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-07-22 10:32:55 AM.