



# MacBook Pro 15" Retina Display Mid 2015

## Lower Case Replacement

Replace the lower case on the MacBook Pro 15" Retina Display Mid 2015.

Written By: Andrew Optimus Goldheart



## INTRODUCTION

Use this guide to help you replace a scratched, scuffed, bent or broken bottom panel on your MacBook Pro 15" Retina Display Mid 2015.

### TOOLS:

- [P5 Pentalobe Screwdriver Retina MacBook Pro and Air \(1\)](#)

### PARTS:

- [MacBook Pro 15" Retina \(Late 2013-Mid 2015\) Lower Case \(1\)](#)
- [MacBook Pro Retina \(2012 to 2015\) Lower Case Screw Set \(1\)](#)

## Step 1 — Lower Case



- Remove the following P5 pentalobe screws securing the lower case to the MacBook Pro:
  - Eight 3.1 mm
  - Two 2.3 mm



## Step 2



- Lifting from the edge nearest the clutch cover, lift the lower case off the MacBook Pro.

### Step 3



-  The lower case has two plastic pegs (red) that fit into plastic clips in the upper case (orange).
-  During reassembly, gently push down the center of the lower case to reattach the case to its two plastic clips.

To reassemble your device, follow these instructions in reverse order.