



Nikon N2000 (F301) Lens Mount Replacement

How to remove the lens mount from the camera.

Written By: Zachary Phillips



INTRODUCTION

If you are having trouble mounting the lens and you are sure you have the correct lens type (see the [camera manual](#) for types of lenses that can be used), then use this guide to assist with replacing the lens mount.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)

Step 1 — Lens Mount



- Use a 00 Phillips head screwdriver to remove the four screws from the lens mount.

Step 2



- Remove lens mount from the camera.
- ⚠ Be careful not to lose any of the three loose pieces that are under the lens mount.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-22 07:48:46 PM.