



How to clean Nikon N2000 (F301) battery corrosion

How to clean out corrosion from the batteries.

Written By: Zachary Phillips



INTRODUCTION

Corrosion usually occurs in the battery compartment. It appears as a light blue coating on any metal components and prevents power from flowing in the camera.

TOOLS:

- [CLR or Vinegar](#) (1)
 - [Cotton Swab](#) (1)
 - [Coin](#) (1)
-

Step 1 — How to clean Nikon N2000 (F301) battery corrosion



- In this guide we will be referring to 'left' and 'right' as though the camera's front (the part that says Nikon) facing you.
- Use a quarter to twist open the one large screw on the bottom case. (No picture available.)

Step 2



- Pull up on the tab to remove the batteries.
- ⓘ Note: The batteries will probably fall out of their holder.

Step 3



- Your camera should look something like this.
- Clean the marked areas with a cotton swab soaked in CLR or vinegar.

Step 4



- Corrosion appears as the bluish build-up you see in this picture. Scrub with a cotton swab until it has visibly decreased.

Step 5



- All cleaned up!

Reinsert the batteries by following the instructions backwards. If it's still not getting power, head over to our [battery compartment replacement guide](#). Note: It may be tough to find replacement parts.

This document was last generated on 2019-07-10 07:26:00 PM.