ASUS VivoBook S300C Hard Drive Replacement

This Guide will accomplish how to remove the hard drive in the asus VivoBook S300C

Written By: Cameron

This document was generated on 2021-01-27 06:41:15 PM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 1 of 5

INTRODUCTION

This Guide will accomplish how to remove the hard drive in the asus VivoBook S300C

🔧 TOOLS:

- Phillips #0 Screwdriver (1)

*Used to disassemble the system*

- Jimmy (1)

Can be used as an aid to remove the bottom cover.

Step 1 — Remove the bottom cover

- Remove the 10 screws on the back cover.

- ⓘ Some screws are missing from this system. You should take your own notes to make sure you put the correct screws in during reassembly.

This document was generated on 2021-01-27 06:41:15 PM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 3 of 5

Step 2 — Remove the hard drive cable

- Remove the hard drive from the laptop. To do this, the cable is taped to the hard drive caddy. Remove the tape from the cable and disconnect the hard drive from the motherboard.

- ⓘ I am also missing screws here. Take your own notes to avoid misplacing screws during reassembly. They should all be the same length.

Step 3 — Remove the hard drive from the caddy

- Remove the 4 screws holding the hard drive in the caddy. There are two screws on each side.

This document was generated on 2021-01-27 06:41:15 PM (MST).

Step 4

- Reassemble the laptop by following the steps in reverse order. This is my first guide, so let me know what I did wrong so I can fix it.

To reassemble your device, follow these instructions in reverse order.