



PowerBook G4 Titanium DVI Battery Replacement

Written By: Walter Galan



INTRODUCTION

Remove the PowerBook G4 Titanium DVI battery.

Step 1 — Battery



- Locate the battery release tab on the underside of the G4.
- Slide the battery release tab to the left and lift the battery out of the computer.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-17 12:01:06 AM.