



iPad mini 4 LTE Display Assembly Replacement

Prerequisite guide for replacing a screen and digitizer, or home button.

Written By: Evan Noronha



INTRODUCTION

prereq only guide for replacing a screen and digitizer, or home button.

TOOLS:

- [iFixit Opening Picks set of 6](#) (1)
 - [Suction Handle](#) (1)
 - [iOpener](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
 - [Spudger](#) (1)
-

Step 1 — Display Assembly



- Use the pointed end of a spudger to disconnect the display data connector from its socket on the logic board.
 - Use the pointed end of a spudger to disconnect the digitizer cable connector from its socket on the logic board.
- When reconnecting these, press down from one end of the connector to the other. If you press in the middle of the connector, you may bend it, causing damage or a poor connection.

Step 2



- Remove the display assembly.

To reassemble your device, follow these instructions in reverse order.