



HTC Maple 100 Battery Replacement

Remove battery

Written By: Andrew Van Meter



INTRODUCTION

The battery could be damaged

Step 1 — Battery



- First remove the back cover of your phone to expose the battery.

Step 2



- Turn the phone over and remove the battery by using your thumb to push forward on the battery and then lift it.

Step 3



- Take the battery out
- ☑ When reassembling, make sure that the battery contacts match up.

To reassemble your device, follow these instructions in reverse order.