




Disassembling Apple IIc Cover

Getting a look inside your computer.

Written By: Alexandria Weinberg



INTRODUCTION

This guide shows you how to remove the cover of an Apple IIc computer. All you need to perform this repair is a screwdriver and something to help open the casing. This is a precursor to any other repair you may want to do on this device and also allows you to get a good look at its internal workings.

TOOLS:

- [Phillips #2 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Disassembling Apple IIc Cover




- Remove the six 19 mm long screws with a #2 Phillips head screwdriver.

Step 2




- Release the catch by pushing it in using a plastic opening tool.
- ⓘ The catch is off-center, but in line with the middle of the speaker underneath.

Step 3



- Slide the case toward the ports on the back, then grip under the catch and pull up while moving toward the ports to remove.

Step 4



- Lift the handle straight up to remove.

To reassemble your device, follow these instructions in reverse order.