




# Access to the main components of the why! N240JU


Written By: Felice Suglia



 **TOOLS:**



- [Phillips #0 Screwdriver \(1\)](#)
-

## Step 1 — Battery




- Start by unlocking the right locking latch.
- Then, by simultaneously unlocking the left latch, lift the battery out of its socket.

## Step 2 — Access to main components



- Begin by spotting the dummy memory card.
- Then, remove it and put it on your workplan.

### Step 3



- Locate the 15 screws that hold the bottom cover of the device in place.
- Unscrew them and place them on your work surface.
- Then, un-clip the bottom cover, starting with the side shown in the third picture.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-01-15 05:45:27 AM.