



Resetting the Palm m105

This guide will instruct you on how to manually reset the device in two different ways.

Written By: Erik Thompson



INTRODUCTION

Make sure you have a paperclip or something similar to push the recessed reset button.

TOOLS:

- [Paper Clip](#) (1)
-

Step 1 — Device Reset



- To soft reset the device, use a paperclip to carefully press the reset button located on the back of the device. The exact location of the button can be seen in the picture.
- ⓘ A soft reset means that it will usually not affect your personal data on your device, unless the batteries are low.
- After you press the button, the device will reboot as if you just powered on your device and it should clear up most common device problems.
- If your device is still not powering up or has a blank display, the next step will help you perform a hard reset of the device.

Step 2



! A hard reset will erase all current data on the device. This should only be done if a soft reset has not solved your problem.

- A hard reset is done by simultaneously holding down the power button while also pressing the reset button on the back with a paper clip like you did for the soft reset. After a few seconds the Palm logo should appear, when it does, release the power button.
- i** If applicable, you can restore any data previously synchronized with your PC through the HotSync operation of the device.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-19 06:18:37 PM.