



iBook G4 12" 1.33 GHz Battery Replacement

Written By: Walter Galan



INTRODUCTION

Changing the battery is easy -- all you need is a coin.

TOOLS:

- [Coin](#) (1)

PARTS:

- [iBook G3 or G4 12" Replacement Battery \(New\)](#) (1)
-

Step 1 — Battery



- Lay your iBook upside down on a flat surface.
- Use a coin to rotate the battery locking screw 90 degrees clockwise.
- Lift the battery out of the computer.

To reassemble your device, follow these instructions in reverse order.