




Nikon CoolPix S600 Battery Replacement

Replacing a dead battery.

Written By: andreas anggasastra



 **TOOLS:**

- [Spudger](#) (1)
-

Step 1 — Battery



- Slide the button towards the center of the camera.

Step 2



- Slide the orange release button towards the center of the camera
- The battery will pop out

To reassemble your device, follow these instructions in reverse order.