




Nikon CoolPix S600 Battery Replacement

Replacing a dead battery.

Written By: andreas anggasastra






TOOLS:

- Spudger (1)
-

Step 1 — Battery



- Slide the button towards the center of the camera.

Step 2



- Slide the orange release button towards the center of the camera
- The battery will pop out

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-08-22 05:07:33 PM.