



iPhone 4S Rear Panel Replacement

Replace a cracked or worn rear panel on your Apple iPhone 4S

Written By: Walter Galan



INTRODUCTION

Remove the rear panel to access the internal components of your iPhone.



TOOLS:

- [P2 Pentalobe Screwdriver iPhone](#) (1)



PARTS:

- [iPhone 4S Blank Rear Glass Panel Fix Kit / Black](#) (1)
This kit contains the part and all tools needed.
- [iPhone 4S Used OEM Rear Glass Panel](#) (1)
- [iPhone 4S Transparent Rear Panel](#) (1)

Step 1 — Rear Panel



- ⚠ Before you begin, discharge your iPhone battery below 25%. A charged lithium-ion battery can catch fire and/or explode if accidentally punctured.
- Power off your iPhone before beginning disassembly.
- Remove the two 3.6 mm Pentalobe P2 screws next to the dock connector.
- ⓘ Be sure the driver is well-seated when removing Pentalobe screws—they are easy to strip.

Step 2



- Push the rear panel toward the top edge of the iPhone.
- ⓘ The panel will move about 2 mm.

Step 3



- Pull the rear panel away from the back of the iPhone, being careful not to damage the plastic clips attached to the rear panel.
- Remove the rear panel from the iPhone.

To reassemble your device, follow these instructions in reverse order.