



Linksys WRT54GS v2 Antennas Replacement

In this guide you will learn how to remove both antennas.

Written By: Allian Roman



INTRODUCTION

In this guide you will learn how the antennas are held in place and how to remove them.

Step 1 — Antennas



- Both of the router's antennas are screwed onto a port.
- To remove the antennas, twist counter clockwise at the base of the antenna and remove each from its port.
- Replacement antennas will screw in clockwise onto each port.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-15 07:26:18 PM.