



LG Voyager Keypad Replacement

How to replace an LG Voyager keypad.

Written By: Faizah Butt



INTRODUCTION

If you are having issues texting or navigating with your keypad, it might be necessary to replace your old keypad with a new one.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)



PARTS:

- [LG Voyager Keypad](#) (1)
-

Step 1 — Keypad




- Power off your phone.
- Turn your phone so that the bottom is facing upwards.
- Remove all four screw covers and screws from the back of the phone with the Phillips #00 screwdriver.

Step 2



- Gently pry open the back of the keyboard.

Step 3



- Pull the rubber keyboard off carefully.

 Be sure not to remove the silver button panel below the keyboard.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-01-15 04:30:30 AM.