



iPhone 4S SIM Card Replacement

Replace the SIM card in your iPhone 4S.

Written By: Walter Galan



INTRODUCTION

Replacing the SIM card in your iPhone 4S is easy. All you will need is an SIM card eject tool or a small paper clip. Follow this guide to replace or remove your SIM card.

TOOLS:

- [SIM Card Eject Tool](#) (1)
-

Step 1 — SIM Card




- Use a SIM card eject tool or a paperclip to eject the SIM card and its holder.

⚠ This may require a significant amount of force.

- Remove the SIM Card tray assembly from the iPhone.

Step 2



- Remove the SIM card from its recess in the SIM card tray.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-10 08:14:40 PM.