



HP Pavilion 14-b120dx Battery Replacement

Prerequisite only

Written By: Erin Lavalla




INTRODUCTION

In this guide, the main objective is to remove the battery from the computer.

Step 1 — Battery



 Power down the laptop and detach the charging cord (failure to do so can result in electrical shock).

Step 2



- Flip the laptop upside down so that the bottom is facing you.
- Push the slide on the right toward the center of the laptop, releasing the battery latch.
- Lift the battery up and away from the laptop.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-10-21 04:26:22 AM.