Dell Latitude E5410 Screen Replacement

This guide will show you how to replace a screen on the Dell Latitude E5410.

Written By: Darby

INTRODUCTION

This guide will show you how to replace a screen on the Dell Latitude E5410.

🔧 TOOLS:

- Mako Driver Kit - 64 Precision Bits (1)
- iFixit Opening Tools (1)
- Spudger (1)

This document was generated on 2020-11-28 05:26:59 AM (MST).

© iFixit — CC BY-NC-SA www.iFixit.com Page 2 of 6

Step 1 — Dell Latitude E5410 Screen Replacement

● Have your laptop ready with your screen pulled all they way down parallel to the bottom of the laptop.

Step 2

● Start on the top left or right corner of the screen edge and unscrew the small screws.

● Be sure to remove the rubber placeholders in order to access the screws.

This document was generated on 2020-11-28 05:26:59 AM (MST).

Step 3

- Using a plastic opening tool, pry the bezel away from the screen.

Step 4

- Use the Phillips screwdriver to remove the screws from corners around the screen.

This document was generated on 2020-11-28 05:26:59 AM (MST).

© iFixit — CC BY-NC-SA | www.iFixit.com | Page 4 of 6

Step 5

- Remove the screws from both sides.

- Once removed, they will release the screen.

Step 6

- Use the spudger to move the sensor aside.

Step 7

- Release the screen by pulling up and out.

To reassemble your device, follow these instructions in reverse order.