




Samsung Galaxy Tab E 9.6 Verizon Speaker Replacement

Speaker replacement for the Samsung Galaxy Tab E 9.6 Verizon.

Written By: Dave Dorzback



INTRODUCTION


This guide will walk you through replacing the speaker on the Samsung Galaxy Tab E.


TOOLS:

- [Suction Handle](#) (1)
 - [Tweezers](#) (1)
 - [iFixit Opening Tools](#) (1)
-


Step 1 — Back Casing




 If the device has a micro-SD or SIM card inserted, remove them from the device before continuing.


 Verify your device is turned OFF after removing all external peripherals from it. Power down the device if it's turned on.

Step 2



- Insert a plastic opening tool in between the edge of the device's screen and its back cover. Once the tool is wedged between the glass and back casing, move the tool around the edges of the device to undo the plastic clips holding the casing attached.
-  Inserting the tool and prying off the back casing requires a good deal of force. If you're having trouble undoing the clips, try using a suction cup on the screen to increase separation with the back casing.

Step 3



- As more clips are undone, it will become easier to further separate the device from its casing. Once you're able to separate roughly half of the device from the back casing, use your hands to gently pull the back cover off of the device.
- ☑ Don't forget: after creating some separation between the device and back case, you can use a suction cup attached to the screen to aid in pulling the device apart.

Step 4 — Speaker



- Locate the speaker in the top right corner of the back casing. Use a pair of tweezers to pull peel up the film connecting the speaker to the case.

Step 5



- Once you've detached the film connecting the speaker to the case, use the tweezers to remove the speaker completely.

To reassemble your device, follow these instructions in reverse order.