



# LG Muziq LX570 Rear Case Replacement

Removing the rear case of the LG Muziq LX570 to access the motherboard and keyboard.


Written By: Matthew Cataldo



 **TOOLS:**

- [Phillips #00 Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
-

## Step 1 — Battery



- Slide the battery cover release towards top of phone.
- Place one finger at each side of the battery cover.
- Lift and remove the battery cover.

## Step 2



- Place a finger at the top corner of the battery and lift out of the phone.

### Step 3 — Rear Case



- Use the spudger to lift up the two screw covers at the top of the phone.
- Remove all four Phillips#00 (3.3mm) screws with screwdriver.

### Step 4



- Use the spudger to lift up the rear case from the phone.
- ⓘ **Note:** Rear case is connected on all sides and will have to be detached on all sides before removal.
- Remove the rear case from the device.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 06:25:31 AM.