




How to replace LCD connector on a A1465 MacBook Air

Step by Step instructions for repairing LCD backlight circuit on A1465 MacBook Air 11" Main Logic Board 820-00164-A

Written By: Forza Vale



INTRODUCTION

Step by Step instructions for repairing LCD backlight circuit on A1465 MacBook Air 11" Main Logic Board 820-00164-A

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 04:57:23 AM.