



Nortel Networks i2004 IP Handset Replacement

This guide will help you install a new handset.

Written By: Morgan Zandonella



INTRODUCTION

This guide will help you replace the handset in your Nortel Networks i2004 IP telephone. You may need to replace your handset if the microphone or speaker in the handset is not working.

Step 1 — Handset



- Turn the phone over to view the underside, where the handset cord connects.
- Disconnect the handset cord from the back of the telephone by squeezing the clip and pulling straight out.

Step 2



- Disconnect the telephone cord from the handset by squeezing the clip and pulling straight out.

Step 3



- Connect the new handset by squeezing the clip attached to the phone cord and sliding the cord into the bottom slot of the phone.

To reassemble your device, follow these instructions in reverse order.