Asus Eee PC 1005HA RAM Replacement

Install new RAM in your Asus Eee PC 1005HA.

Written By: Mitchell Cesare

INTRODUCTION

Use this guide to replace or upgrade RAM in the Asus Eee PC 1005HA.

TOOLS:

- Phillips #1 Screwdriver (1)

PARTS:

- PC2-6400 2 GB RAM Chip (1)

This document was generated on 2020-11-28 02:28:30 AM (MST).

Step 1 — RAM

- Loosen the captive screw in the RAM compartment cover.

- Remove the RAM compartment cover.

- ⓘ This photo shows the battery still attached, but it should be removed prior to removing or replacing the RAM.

Step 2

- Pull the two RAM retaining arms away from the center of the RAM chip.

- Gently pull the RAM chip out of its socket.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-11-28 02:28:30 AM (MST).