



# ZTE Maven Battery Replacement

Follow this guide to remove and replace the battery for the ZTE Maven.

Written By: Gigabit87898

## INTRODUCTION

Follow this guide to remove and replace the battery for the ZTE Maven.

---

### TOOLS:

- [Phillips #0 Screwdriver](#) (1)
  - [iFixit Opening Picks set of 6](#) (1)
  - [iOpener](#) (1)
-

## Step 1 — Battery



- Remove the back cover.

## Step 2



- If inserted, remove the SIM card and SD card.

### Step 3



- Remove midframe screws.

### Step 4



- Carefully pry between the screen and midframe to release the clips holding it on.

## Step 5



- Remove the midframe.

## Step 6



- [Heat an iOpener](#) and lay it over the battery for one minute.

## Step 7



- Carefully, with a pry pick, pry under the battery to cut the adhesive underneath it.
- If you are having trouble, apply a heated iOpener onto the battery for another minute, then try again.
- You can also apply a few drops of high concentration isopropyl alcohol to the edges of the battery to help soften the adhesive.

## Step 8



- Remove the battery.

---

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-05-12 01:44:43 PM.