



Disassembling Sirius Stiletto 100 Front Cover

Remove the front cover to access the inner parts of the mechanism.

Written By: Trey



 **TOOLS:**

- Phillips #0 Screwdriver (1)
 - Spudger (1)
-

Step 1 — Front Cover



- Remove the battery (which also functions as the back cover) from the device. This step is not explicitly shown, but a picture without the battery cover shows the device post-battery removal.

Step 2



- Use a Philip's head screw driver to remove the screws from the case.
- Place the screws in a small container to avoid losing them.

Step 3



- Remove the front cover.
 - First, insert a small pry bar where the black front cover and white back cover meet.
 - Begin prying the black plastic up, slowly moving around to the bottom and other side.
 - At an angle, carefully pull up on the front cover separate the two pieces.
 - Excellent! Now you have removed the front cover!

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-21 02:18:29 PM.