



# Motorola C168 Battery Replacement

Instructs user on how to properly remove and replace a defective battery.

Written By: Christopher Wu





## PARTS:

- [Motorola C168 Replacement Battery](#) (1)
-

## Step 1 — Battery



- Turn the phone so its back is facing you.
- Press the release button on the back cover, while simultaneously pulling the cover down.
- Remove the back cover.

## Step 2



- Pinch the sides of the bottom of the battery and pull upward.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-11-22 06:53:22 AM.