



2002-2006 Cadillac Escalade Coolant Replacement

A video tutorial on how to change the coolant on a 2002-2006 Cadillac Escalade.

Written By: eCuration



INTRODUCTION

The engine coolant should be flushed and replaced once every 30,000 miles.

Follow this video tutorial by YouTuber [NutzAboutBolts](#) to complete the change yourself.



TOOLS:

- [Long Neck Funnel](#) (1)
- [Oil Drain Pan](#) (1)



PARTS:

- [Engine Coolant](#) (1)

To reassemble your device, follow these instructions in reverse order.