



2003-2007 Honda Accord Brake Fluid Replacement

A video tutorial on how to change and flush the brake fluid on a 2003-2007 Honda Accord.

Written By: eCuration



INTRODUCTION

The brake fluid should be flushed and replaced once every 5 years.

Follow this video tutorial by YouTuber [NutzAboutBolts](#) to complete the job yourself.

TOOLS:

- [Hydraulic Floor Jack](#) (1)
- [Jack Stands](#) (1)
- [Wheel Chocks](#) (1)
- [Brake Bleeder Bottle](#) (1)
- [10mm Wrench](#) (1)
- [8mm wrench](#) (1)

PARTS:

- [Brake Fluid](#) (1)

To reassemble your device, follow these instructions in reverse order.