



# 2003-2007 Honda Accord Coolant Replacement

A video tutorial on how to change and flush the coolant system on a 2003-2007 Honda Accord.

Written By: eCuration



## INTRODUCTION

The coolant should be replaced every 30,000 miles.

Follow this video tutorial by YouTuber [NutzAboutBolts](#) to complete the change yourself.

---

### TOOLS:

- [Spill Free Funnel](#) (1)
- [Oil Drain Pan](#) (1)

### PARTS:

- [Engine Coolant](#) (1)
-

To reassemble your device, follow these instructions in reverse order.