




Acer Aspire One Cloudbook AO1-132-C3T3 USB Port Replacement

This guide will help you remove and replace the USB Port on your device.

Written By: Brian Villa




INTRODUCTION

In this guide, you will remove the USB Port from the device by removing two screws and disconnecting the ribbon cable connecting it to the motherboard.

TOOLS:



- [Phillips Head Screwdriver: Size PH1 \(1\)](#)
-

Step 1 — USB Port





- Remove eleven 4 mm Phillips #1 screws
- Pull the backplate off using your fingers.

Step 2



- Remove the two screws holding down the USB Port.

Step 3



- Now that the port can be lifted up, remove the ribbon cable by using the sticker attached to it.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-01-12 08:07:07 PM.