



Asus X501A-RH31 Battery Replacement

Effectively remove a battery from Asus X501A-RH31.

Written By: Romana Hruby



INTRODUCTION

Battery removal is an important step to take before any further disassembly or repair.

Step 1 — Battery




- Turn the laptop over so that the back is facing upwards.

Step 2



- To unlock the left tab, make sure the tab on the left has red showing.

Step 3



- To unlock the right tab, push the right slider to the left with one hand.
- Push the battery out with the other hand.

To reassemble your device, follow these instructions in reverse order.